

***This page contains important safety instructions to be followed when using electric devices commercialized by SC Johnson***



## **GLADE PlugIns – Liquid Electric**

Version 2.0

Revision Date 01.02.2020

**IMPORTANT SAFETY INSTRUCTIONS:** Instructions to avoid the hazards of fire, toxicity, electric shock, or injury. **PLEASE READ BEFORE USING AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS.** **WARNING:** when using electrical appliances, basic precautions should always be followed including the following: **CAUTION:** This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. For safe use, plug only into properly functioning wall outlets where device is ventilated and cannot contact bed covering or other material. Do not use with extension cords or multi-plugs. Do not immerse in water. Do not insert anything into outlet above it. The appliance is only to be used with the recommended vaporizing medium. The use of other substances may give rise to a toxic or fire risk. **KEEP OUT OF REACH OF PETS.** These instructions are available at [[www.scjproducts.info](http://www.scjproducts.info)]

Never plug another appliance or cable in an outlet above the warmer device.

Do not allow materials of any kind to cover the device while it is in use.

Do not touch device with metal instruments or wet hands.

Unplug when the refill is empty/exhausted, replace the refill only when the device is unplugged.

The device may become slightly warm while in use

Before plugging the device always check the voltage is compatible with the one reported on the unit

For cleaning, unplug the device and use a dry cloth or paper towel.